




# CPSC 359 – Digital Logic Tutorial #2 Multiplexing

**Andrew Kuipers** 

CPSC 359

































#### Decode the Address

- First, we need to decode the address to select the line
  - Input: n bit address
  - Output: 2<sup>n</sup> selector lines




<b>I1</b>	10	S0	S1	S2	<b>S</b> 3
0	0	1	0	0	0
0	1	0	1	0	0
1	0	0	0	1	0
1	1	0	0	0	1





#### Activate the Line

Use the output of the decoder to activate the correct line




CPSC 359





#### Activate the Line


- 4 to 1 multiplexer
  - 2bit address space
- What we have:
  - Four 1bit inputs
  - One 1bit output
- What we want:
  - Four 4bit inputs
  - One 4bit output







### Exercise







### Challenge Exercises

- 1. Combine the Multiplexer with the 4bit Full Adder
  - Use 4bit Full Adder circuit from lecture
  - Two 4bit 4-to-1 multiplexers to select each input to the adder
- 2. Create a 4bit 1-to-4 Demultiplexer
  - It's like a multiplexer, just in reverse!
  - One 2bit selector and one 4bit value input
  - Four 4bit value outputs